

Installation Instructions for Emigh Trojan

---

1. Turn off fuel.
2. Remove original gascolator. Remove fittings for reuse.
3. Use a gas resistant sealant on all threads during reassembly.
4. Install AN 912-1,1/4 - 1/8 bushing reducers in the ports of the SA3-00 gascolator cover.
5. Reinstall the original fittings into the reducers and install the SA3-00 cover to the firewall outlet.
6. Reconnect the fuel line to the fuel pump.
7. Install the SA3-00 gascolator bowl, safety and turn on the fuel. Check for leaks.
8. Log installation in logs and 337
9. Refer to Instructions for Continued Airworthiness for maintenance.
10. No basic weight change.