

Installation Instructions for Aeronca 15 AC

---

1. Turn off fuel.
2. Remove original gascolator. Remove fittings for reuse.
3. Use a gas resistant sealant on all threads during reassembly.
4. Remove gascolator bracket from firewall and plug small 3/16 hole in firewall with a truss head type 10/32 screw and nut.
5. Assemble bracket to the SA3-10-C gascolator with the small hole up. Install the fitting through the firewall into the SA3-10-C gascolator. The bowl of the new gascolator will be on the bottom and the small hole in the bracket will now be above the gascolator. Using the small hole in the bracket for alignment, drill a new hole through the firewall, and secure with original hardware.
6. Reconnect all fuel lines. Plug any holes not used for fittings. Turn on fuel and check for leaks.
7. Log installation in logs and 337.
8. Refer to Instructions for Continued Airworthiness for maintenance.
9. No basic weight change.