

Dated 1-31-2003

I.R.

Rev. 1 dated 5-24-2007

---

Installation Instructions for Cessna 310

---

1. Turn off fuel and remove cowling.
2. Disconnect fuel lines and remove original gascolator.
3. Remove fittings from original gascolator and install them in the SA3-10-A gascolator, paying attention to orientation. Fitting MS20822-6-6D should be installed in the inlet and outlet positions.
4. Install the SA3-10-A gascolator to the mount bracket using new, or original AN hardware. Observe fuel flow direction.
5. Reinstall all fuel line connections. If remote drain system is used, reinstall and adjust. Secure the bowl with a cotter key or .32 min safety wire, turn on fuel and check for leaks. Observe operation of remote drain and adjust if necessary.
6. Reinstall cowling.
7. Log installation in logs and 337.
8. Refer to Instructions for Continued Airworthiness for maintenance.
9. No basic weight change.